

Please note: The live feed taken from the fan speed controller is to be passed through the hole in the centre of the CS switch and wrapped around the coil to increase sensitivity of the current sensor.

240 VOLT MAINS LIVE
NEUTRAL
EARTH
LOW VOLTAGE



All discrepancies between information shown on the drawing and information in the specification to be referred to \$ & \$ Northern prior to proceeding.

Copyright in all documents and drawings prepared by \$ & \$ Northern and any work executed from these documents and drawings shall, unless otherwise agreed, remain the property of \$ & \$ Northern.

Amendments		
icale N.T.S.	Date	Drawn JEB

Drg. No.