

# **Emergency Stop Buttons EP-EM**

Page 1 of 1

## **Description**

The range of emergency stop switches are for use in the manual shut down of systems in the event of fire or other emergency.

#### **Features**

- Twist or key reset versions
- Metal Boxed Versions
- 6A @ 230Vac rated





## **Technical Specification**

Reset Type: Twist reset

EP-EM1K, EP-EM1M-K - Key reset

**Switch Rating:** 10(6)A @ 240Vac SPDT Housing Dimensions: 80 x 73 x 50mm

# Installation

#### Warning:

Hazardous voltage can cause electrical shock. Disconnect power before proceeding with any work on this equipment.

- 1. Separate switch base and top
- 2. Mount using the base as a template for holes
- 3. Knock out hole at top or bottom of base to allow cable entry
- 4. Feed cable through a cable gland and hole
- 5. Make necessary electrical connections
- 6. Replace switch top

Note: Key is captive on key reset models when the switch is in the unlatched position

## **Typical Wiring Connections**

**Plastic Housing Versions:** 

Contact Block situated inside base of housing



Find out more **S&S Northern Ltd** www.snsnorthern.com

