



Legend

- 1) A 230-Volt electrical supply should be supplied to the panel. This should be externally fused at 3 Amps using a fused spur and should be connected to the terminals marked "LNE Power".
 - 2) The gas solenoid valve should be powered using the terminals on the Merlin 1000SW+ marked "Gas Valve".
 - 3) The electric contactor power output is 230VAC.
 - 4) The water solenoid valve should be powered using the terminals on the Merlin 1000SW+ marked "Water Valve".
 - 5) This terminal is disabled on this system.
 - 6) This terminal is disabled on this system.
 - 7) Terminals connections are available on the circuit board for connections to Building Management systems. This terminal should be wired using low voltage cable.
 - 8) The terminals marked pressure sensor "+ - IN". These wire to the gas pressure transducer which is screwed into the downstream port of the gas solenoid valve. Please ensure this is wired as instructed. Minimum operating pressure = 12Mbar Maximum operating pressure = 100Mbar.
 - 9) The terminal for remote emergency shut-off buttons is detailed on the circuit board as "EM Remote". These connections are linked out as a factory setting. Remote emergency shut-off buttons should be volt free and wired to the Merlin 1000SW+ using two-core cable.
 - 10) The terminals detailed on the circuit board as "Gas Detector". These connections are "+,-" and "L_J", these can be wired to a Merlin Natural Gas, Carbon Monoxide or LPG detector. If no detector is being used leave the link in between the "L_J". Other detector types are available.
 - 11) This terminal switches when the key is turned on and off. This can be linked to a fan switch (panel supplied separately) which can provide power to the fans when the control panel is switched on.
 - 12) This terminal can be wired to CO2 monitor to shut off the system in the event of CO2 being at alarm level. If no CO2 monitor is supplied leave the terminal link in.
 - 13) This is a permanent 12v DC output when there is power at the panel.
- Note: All low voltage connections should be made using a screened cable. To avoid electrical interference this should not be in the same conduit as mains cable as per the low voltage directive.
For further information please refer to S&S Northern operating and installation instructions.

- 230 VOLT MAINS LIVE
- NEUTRAL
- EARTH
- LOW VOLTAGE



Client	
Job Title	
Drawing Title	

Notes
All discrepancies between information shown on the drawing and information in the specification to be referred to S & S Northern prior to proceeding.
Copyright in all documents and drawings prepared by S & S Northern and any work executed from these documents and drawings shall, unless otherwise agreed, remain the property of S & S Northern.

Amendments		
Scale N.T.S.	Date	Drawn BT
Dra. No. 1000SW+		Rev. 1