

## Description

The range of emergency stop switches are for use in the manual shut down of systems in the event of fire or other emergency.



## Features

- Twist or key reset versions
- Metal Boxed Versions
- 6A @ 230Vac rated

## Technical Specification

<b>Reset Type:</b>	Twist reset EP-EM1K, EP-EM1M-K – Key reset
<b>Switch Rating:</b>	10(6)A @ 240Vac SPDT
<b>Housing Dimensions:</b>	80 x 73 x 50mm

## Installation

### Warning:

Hazardous voltage can cause electrical shock. Disconnect power before proceeding with any work on this equipment.

1. Separate switch base and top
2. Mount using the base as a template for holes
3. Knock out hole at top or bottom of base to allow cable entry
4. Feed cable through a cable gland and hole
5. Make necessary electrical connections
6. Replace switch top

**Note:** Key is captive on key reset models when the switch is in the unlatched position

## Typical Wiring Connections

### Plastic Housing Versions:

Contact Block situated inside base of housing



Find out more  
**S&S Northern Ltd**  
[www.snsnorthern.com](http://www.snsnorthern.com)

Head office:  
Wallace Francis House, Barnes Wallis Way, Lancashire, PR7 7JN  
Tel: 01257 470983  
Email: [info@snsnorthern.com](mailto:info@snsnorthern.com)

